

# Elektronik-Stromwandler

Funktion	Stromerkennung ja/nein				Messumformer für AC-Strom			Strom-erkennung
	Strom-sensorS1	STWA1S	STWA1SH	STWA1SEH	STWA1AH	STWA2AH	STWA1FH	
Messeingang	AC/DC	AC	AC	AC	AC	AC 0-20/ 0-100 A	AC 0-20 A	AC
Ansprechwert	5 A/5-30 A	2 A	2 A	2-10 A	-	-	-	2-20 A
Ausgang	Transistor +/-	Transistor	Transistor	Transistor	DC 0-20 mA	DC 4-20 mA	Transistor 0,5-20 Hz	Triac 0,5 A
Gehäuse	S 1	Ø 34,5 mm	H	H	H	H	H	H

